

## Open cooling towers

## Options and accessories

## **Remote sump connection**



To protect sump water from freezing you can use an auxiliary remote sump within a heated space.

Using a remote sump

- guarantees year-round reliable operation
- helps improve system hygiene

Just follow some simple guidelines when <u>selecting your remote sump tank</u> for a VTL-E cooling tower.

Want to use a remote sump? Contact your <u>local BAC representative</u> for guidance.