Open cooling towers

Options and accessories

Remote sump connection



To protect sump water from freezing you can use an auxiliary remote sump within a heated space.

Using a remote sump

- guarantees year-round reliable operation
- helps improve system hygiene

Just follow some simple guidelines when selecting your remote sump tank for a RCT open cooling tower.

Want to use a remote sump? Contact your local BAC representative for guidance.

This file has been generated from the BAC website on: 28/03/2024
For more up to date information, visit: https://www.baltimoreaircoil.eu/en/products/RCT-remote-sump-connection