

## Open cooling towers

## Options and accessories

### Safety switch



This switch

- facilitates inspection and maintenance
- prevents accidental risks during inspection or maintenance

The switch safely isolates the motor and cuts the power. It is installed in a lockable box and shipped loose with cable glands for field installation and wiring. Upon request, factory mounting and electrical connection between motor and switch is possible for some models.

Contact your [local BAC representative](#) for guidance.